
## Document shredders DAHLE 106





## Document shredders DAHLE 106







Separate main switch is located on the rear of the document shredder and completely disconnects it from the mains power supply



Detachable IEC power plug makes the document shredder quick and easy to move from A to B




Pull-out rounded top frame that's kind on the fingers when changing the waste bag



## Document shredders DAHLE 106



Separate, integrated waste boxes help to sort shredded paper, CDs, DVDs, cheque and credit cards for eco-friendly recycling



P-2 security: recommended, for example, for data media containing internal data that are to be made illegible

